

Post sockets - SUPPLY ONLY



Details

These sockets are required for the following posts:

- Socketed badminton posts
- Rebound screens
- Socketed Multinet posts

Each socket must be set securely in a concrete floor using a resin such as Kemfix and two sockets are necessary for one pair of posts.

The sockets are provided with removable drop-in dust covers to provide a smooth finish to sockets installed flush with your finished floor (e.g. a vinyl surface directly onto a concrete sub-floor)

If your floor is a sprung floor, the socket must be set underneath the finished floor and removable bushing covers will be necessary to be installed in your floor to provide access to the socket. The dust cover isn't necessary with this type of installation.

If you would prefer Continental's in-house installation engineers to install your socketed badminton posts, please add the required quantity of sockets and the same number of "Post Socket Installation" items to your basket.