

NOTES

We provide a timber wallpad, $3660 \times 95 \times 45$ mm which is positioned horizontally at any height to suit the wall conditions.

The wallpad is best secured with 7No M10 50L rawlbolts, but depending on the structure it can be fixed with coachscrews or drilling and tapping for bolts.

The wallpad bracket as detailed on dwg No WHCF-08 is held with 4No 8mm dia x 45mm long coachscrews. The frame bracket as detailed on dwg No WHCF-08 which is fixed with 4No No12 x 32mm long c/sk headscrews acts as the hinge The floor pivot bracket locates in to the same centre line as the bracket above.

The tension clamp housing is fixed with 3No countersunk head woodscrews to a $560 \times 95 \times 45 \text{mm}$ timber wallpad twice rawlbolted to the wall.

The locking bracket is fixed with 2No 8mm dia \times 45mm coachescrews to a 560 \times 95 \times 45mm timber wallpad twice rawlbolted to the wall.



dwg no

WHCF-09