



www.continentialsports.co.uk

PVC COVERED WALL AND FLOOR PADDING



OPERATION

A visual check of wall and floor pads should be undertaken prior to each use to ensure they are present and undamaged.

If there is damage to the PVC upholstery on any floor pads they should be repaired / replaced immediately to prevent any holes becoming toe traps

Minor damage to PVC upholstery on wall padding does not cause a hazard to users but can become a potential hazard if any holes are made worse through misuse (picking / tearing by users)

MAINTENANCE

Small tears and holes in PVC upholstery can be patch repaired using a small patch of PVC fabric glued using a suitable PVC adhesive – contact Continental to purchase a patch repair kit if required.

CLEANING

To clean PVC covered wall or floor pads use a damp cloth with soapy water and wipe. Antibacterial spray may be used on the PVC coated padding and the bed, but test an inconspicuous area first to ensure no white residue is left when the spray dries.