



www.continentalsports.co.uk

BADMINTON POSTS - SOCKETED



OPERATION

1. Place a post in each socket on the court. Rotate the posts so that the clam cleat faces out of the court and the post drops onto the locating pin in the socket to prevent rotation
2. Attach one end of the net headline to the tie-off cleat on one post using multiple figure of eights and pass the headline through the clam cleat above the tie-off cleat
3. Span the net to the opposite post, passing the headline through the clam cleat.
4. Pull the net headline taught through the clam cleat on the second post before tying off the net on the second tie-off cleat
5. Adjust the net tension as necessary by pulling the headline through the clam cleats and sliding the net along the headline if it is not central.
6. Clip the sides of the net into the net hooks located on the inside of each post

STORAGE

7. We recommend posts are stored on a Continental Sports storage base or trolley when not in use.
8. To store the nets, detach from the posts, fold the headline repeatedly and then roll the net into a sausage shape and insert into the net storage pouch to prevent snagging when in storage. The net storage pouch can be hung on the tie-off cleat on the posts when in storage

See recommendations in the Continental maintenance manual concerning regular maintenance inspections and reports.