



www.continentalsports.co.uk

BADMINTON POSTS - STANDARD



1. Put badminton posts in place
2. Place headline of net in V-shaped recess on the top of the upright
3. Attach headline to the cleat using multiple figure of eights
4. Attach bottom corner of the net to the tie-off cleat
5. To use the posts for short tennis, invert the posts and tie off the headline of the net on the lower cleat

See recommendations in the Continental maintenance manual concerning regular maintenance inspections and reports.