

Rebound screen lifting bars



Details

These nickel plated bars are designed to fit in the integral lifting holes in the end panels of sports hall rebound screens from Continental Sports

To remove or insert a rebound screen panel:

- Two people use one lifting bar each
- Simply insert the bar through the hole in each end of the board
- Place one hand on the bar on one side of the board and the other hand on the bar on the other side of the board, and lift the board