

SECURING ARRANGEMENTS FOR INDOOR GOALS WALL SECURING SYSTEM





IMPORTANT It is imperative that indoor goals are anchored to prevent accidents which could otherwise be caused by the goals toppling.

- 1. Continental provides anchorage fittings into walls or floors for 5-a-side football goals and hockey goals
- 2. Each goal has a threaded socket centrally along the back of the crossbar.
- 3. An eyebolt is to be located into the socket on the crossbar and screwed in tightly
- 4. Steer the goal into position opposite the eyebolt protruding from the wall, and set up the goal ready for use. Align the eyebolt on the goal with that in the wall
- 5. From the eyebolt at the back of the goal extend the PVC coated steel cable and snap hook to the eyebolt in the wall
- 6. Connect the snap hook to the wall eyebolt to secure the football or hockey goal
- 7. Regularly check all items for wear. If replacements are necessary, contact Continental.

CAUTION

The PVC coated steel cable MUST be removed and kept with the goal when the goal is not being used. DO NOT leave the cable hanging from the eyebolt in the sports hall when the goal is not in use as this is a potential hazard.

See recommendations in the Continental maintenance manual concerning regular maintenance inspections and reports.