


SRX (FIXED HEIGHT) VOLLEYBALL POSTS



SAFETY REGULATIONS

In order to reduce the risk of injury and to assure secure functioning of the apparatus, rules mentioned below are to be strictly followed:

1. Use this apparatus only under the supervision of a trained and qualified instructor.
2. Check this apparatus for proper stability before each training, use it only in perfect technical conditions.
3. Always check the apparatus for its correct installation, particularly for the fixation mechanism, before each use. If there are any doubts, do not use the apparatus and get a professional check.
4. Please consider your own limits and the restrictions of this apparatus.
5. Obstructive items or persons in close proximity of the apparatus are not allowed.
6. Provide appropriate safety zones in the surroundings of the apparatus.
7. Never use the apparatus under the influence of alcohol, medication or drugs.
8. Pregnant women or persons with health issues should not use the apparatus.
9. Do not attempt to repair any damage to the apparatus yourself but contact your supplier for advice or technical assistance.
10. Any unauthorised repair, alternation, removal of parts or change of specifications of the apparatus are strictly prohibited for reasons of safety and will automatically and immediately and without any prior notice end any warranty or right of compensation in any form whatsoever.

GENERAL ADVICE


The life period of apparatus is limited. Also materials wear after a certain period of time. Please check all parts, which are subject to severe wear and tear, at least once every 3 months. This is mainly relevant for the security of adjustable parts and mechanisms, e.g. rails, bars, rings. Replace any worn off, defective and missing parts. If there are any doubts, ask for advice from one of our specialists.

For security reasons, we suggest to perform a maintenance check of all apparatuses and mats by a specialist, once a year. This check can be part of a yearly or six month safety check.

This apparatus is designed to be used in dry conditions only.

SETUP

The setup and storing of this device may only be undertaken by competent adults who have read and understood the safety regulations of this manual.



Place (do not drop) both the posts, in the floor sockets and make sure the mounting points face inwards.

On the side of the post with net fixing, attach the Kevlar suspension cable to the quick link on one end of chain and attach the other end of the chain to the eye of the net attachment slide.


On the side of the post with the SRX-tension system, attach the suspension cable to the Kevlar cord of the SRX net-tension system.

Make sure the tension indicator is orange.

This ensures there is no tension on the SRX-system.

When setting up the volleyball set for the first time it might occur that during pre-tensioning the net, the chain is too long and needs to be shortened a few shackles in order to reach the correct pre-tension on the net






Slide the net-height adjusters on both posts to the point where the cord (at the post) reaches a height of 2,50m. Tension the net at this point.

Tensioning the net is done as followed.

Take the cable grip and pull the Kevlar cable.



When placing the oval height indicator stickers, take in consideration that all floor sockets at the venue may not be exactly the same depth, therefore ensure each post always uses the same floor sockets to ensure the height indication sticker is always correct.


The height shown on the post is not the real height from the floor – it is calibrated by the user setting the height of the net in a specific socket.




Pre-tension the net using the cable grip.

Pull the Kevlar cable and fix the cable grip behind the pawl on the net-tension system.

Further tension the net by turning the spindle clockwise until the green area is in line with the spindle housing.






Slide the lower net tensioners up to the net-height adjusters and attach the net-tension ropes. Pull the net tensioners down to pre-tension the net.

Now pull the net tensioners further down until the net's midpoint reaches 2.43m.

Securely fix the net using the 6 lines supplied with the volleyball set.

Attach the pockets and the antennae to the net



Now place the oval orange sticker on the net-height adjuster at the same height as the volleyball-marking on the post (= 2.43m).

The height indication on the post is not the exact height measured from the floor. This height indication is, in combination with the orange indicator on the slide, a helpful tool for future set-ups. (when using the same combination and ground sockets).

To dismantle the volleyball set, repeat the above steps in reverse.

In order to release all tension on the suspension cable, turn the handle counter clockwise until the tension-indicator turns orange

